

Assembly advice

Although the 32mm bearings have major performance advantages they are sensitive to over tightening. Do NOT over tightened bearing housings as this will cause bearings to fail prematurely.

The spacers provided behind the cranks are critical to smooth running of your bearings. Do NOT replace the spacers with non-standard spacers.

When replacing cranks do NOT overtighten the crank bolts as this will cause bearings to fail.

If in doubt while building or servicing your Unicycle please contact your retailer.

